


Down Spout Filter Blind Insert

Down Spout Filter Blind Insert is used to restrict rainwater from entering the storage tank. Simply remove the stainless steel mesh filter and replace it with the Blind Insert.



NOT TO SCALE

o f

m N N i o

w o

S O O . O N g . S g g T o o o o o N c i . g T Z Z O U D N Q Z D W H U P D Q D J H